110794

CATALOGED BY SEPIR

20070917069

DEVELOPMENT TEST SUMMARY IN SUPPORT OF X-20 ELEVON STRUCTURAL TEST PROGRAM

JOHN C. GROGAN

TECHNICAL REPORT AFFDL-TR-65-191

JANUARY 1966

AIR FORCE FLIGHT DYNAMICS LABORATORY
RESEARCH AND TECHNOLOGY DIVISION
AIR FORCE SYSTEMS COMMAND
WRIGHT-PATTERSON AIR FORCE BASE, OHIO

Distribution of This Document Is Unlimited.

NOTICES

When Government drawings, specifications, or other data are used for any purpose other than in connection with a definitely related Government procurement operation, the United States Government thereby incurs no responsibility nor any obligation whatsoever; and the fact that the Government may have formulated, furnished, or in any way supplied the said drawings, specifications, or other data, is not to be regarded by implication or otherwise as in any manner licensing the holder or any other person or corporation, or conveying any rights or permission to manufacture, use, or sell any patented invention that may in any way be related thereto.

Copies of this report should not be returned to the Research and Technology Division unless return is required by security considerations, contractual obligations, or notice on a specific document.

DEVELOPMENT TEST SUMMARY IN SUPPORT OF X-20 ELEVON STRUCTURAL TEST PROGRAM

JOHN C. GROGAN

Distribution of This Document Is Unlimited.

FOREWORD

This report was prepared by John C. Grogran of the Project Engineering Group, Structures Test Branch, Structures Division of the Air Force Flight Dynamics Laboratory, Wright-Patterson Air Force Base, Ohio. It contains a general summary of significant results obtained during the development test program conducted in preparation for the X-20 Elevon Structural Test Program.

This report covers work conducted from January 1964 to July 1964.

The manuscript of this report was released by the author September 1965 for publication as an RTD Technical Report.

The research and development work upon which the report is based was accomplished under Task No. 136804, "Re-entry in Hyperthermanic Structures," of Project No. 1368, "Structural Design Concepts."

This technical report has been reviewed and is approved.

FRED J. PECK, JR./ Chief, Structures Test Branch

Structures Division

ABSTRACT

The contents of this report are oriented exclusively toward test procedures, test hardware and test techniques involving advanced type structures. It contains a general

summary of significant results obtained during the development test program conducted in preparation for the X-20 Elevon Structural Test Program,

CONTENTS

SECTION		PAGE
I	Introduction	. 1
п	Discussion	. 2
III	Summary and Conclusions	. 8

ILLUSTRATIONS

FIGURE		PAGE
1	Specimen and Lamp Arrangement for Power Requirements Tests	9
2	Power Required (KW/ft 2) v.s. Distance from Lamps to Specimen	10
3	Power Increase (% from 2 inch Reference) v.s. Distance from Lamps to Specimen	10
4	Temperature Lag Under LT-1200 Lamp Holders v.s. Temperature Level	11
5	X-20 Elevon Time-Temperature Program	12
6	Temperature Distributions on Corrugated René 41 Panel	13
7	Temperature Distributions on Slotted Research, Inc. Water Cooled Reflector	14
8	X-20 Elevon Slotted Water Cooled Reflector	15
9	Temperature Distribution on Rod in Close Proximity to Heat Lamps	16
10	Test Set-Up for Load Rod Temperature Tests	17
11	Temperature Distribution on Thin René 41 Load Strap in Close Proximity to Heat Lamps	. 18
12	Load Strap and Heater Arrangement on X-20 Elevon	. 19
13	Time Temperature Program for Heater Evaluation	. 20
14	Thermocouple Switching System Used for the X-20 Elevon Test Program	. 21
15	Comparison of Actual Load and Programmed Load from Edison	. 22

SECTION I

INTRODUCTION

- 1. This report is a summary of significant results obtained during the development test program conducted in preparation for the X-20 Elevon Structural Test Program. The areas that will be covered are those that are considered to have general application to forthcoming structural test programs. A brief outline of the topics to be covered are presented below:
- a. Power requirements for lamp to specimen distances of 2, 3, 4 and 5 inches (see Paragraph 1, Section II).
- b. Temperature gradients on the specimen in the shaded areas of the Lux-Therm (LT 1200) ceramic double lamp holders for lamp to specimen distances of 2, 3, 4 and 5 inches (see Paragraph 2, Section II).
- c. Temperature gradients on corrugated panels (that is, temperature differences between peaks and valleys of the corrugations). (See Paragraph 3, Section II).
- d. The temperature distribution on Research, Inc. water cooled reflectors when some water channels are eliminated from the reflector. (On the X-20 elevon set-up, slots had to be cut in the reflectors to permit passage of load straps). (See Paragraphs 4 and 5, Section II).
- e. Data-Trak programmer modifications which permitted controlled temperature decay rates in the event of an emergency abort situation (see Paragraph 10, Section II).

- f. Method to establish proportional band settings to permit good temperature control (see Paragraph 12, Section II).
- g. Back-up system to permit control of one zone with a thermocouple (t/c) from an adjacent zone in the event of a control t/c malfunction (see Paragraph 11, Section II).
- h. Thirty-four channel load system checkout using the Data-Trak as the program generator (see Paragraph 13, Section II).
- i. Modifications to a fatigue Edison unit for time dependent load spikes (see Paragraph 13, Section II).
- j. Temperature distributions on load straps and rods that come in close proximity to heater lamps (see Paragraph 6, Section II).
- k. Temperature limits of stainless steel lamp holders (see Paragraph 7, Section II).
- 1. Optimum point where cooling is required for ceramic lamp holders and lamp quartz envelope (see Paragraph 8, Section II).
- m. Lamp orientation with reference to R.I. reflector water channels (that is, lamps parallel with water channels v.s. lamps perpendicular to water channels). (See Paragraph 4, Section II).
- n. Pyro-Metric Model 602 heater evaluation (see Paragraph 9, Section II).

SECTION II

DISCUSSION

- 1. Power requirements as a function of lamp to specimen distance were determined by oven tests. The test set-up and other pertinent information are presented below:
- a. The oven used for these series of tests was made from 3000°F fire brick and had inside dimensions of 31 inches x 31 inches x 12 inches deep. The oven sides were lined with 3 layers of 1/8 inch thick "Fibrefrax" insulation. Two windows (9" x 2-1/2" Vycor) were provided for visual inspection.
- b. The specimen consisted of a .010 inch Rene' 41 corrugated panel removed from the Boeing Hot Structures Model. It had a trapezoidal shape 22 inches long with end dimensions of 12-1/2 and 17-1/2 inches respec-Thirty-seven chromel-alumel tively. (24-28 gage) thermocouples were welded to the specimen in selected locations to provide data for the tests mentioned in Section I (see Figure 1). The panel specimen was supported by angle sections to minimize warpage and to provide a 3-inch clearance between the bottom of the oven and the specimen. The emissivity of the specimen was approximately 0.80.
- c. Test temperatures were applied by heaters consisting of Research, Inc. water cooled reflectors, Lux-Therm (LT-1200) ceramic double lamp holders (with no cooling air), and Westinghouse 1500, T-3, CL/HT quartz infrared heat lamps. The lamps were oriented parallel to the reflector water channels which were perpendicular to the corrugations of the specimen. The double lamp holders were located in the center between water channels on 1-5/8 inch centers giving an equivalent lamp spacing of 0.812 inches. Each row of lamps was staggered to minimize specimen temperature gradients (See Figure 1 for heater dimensions and layout).
- d. Figure 2 is a plot of power required (KW/ft² reflector) v.s. lamp to specimen distance for the test configuration described

- above. These power data were obtained with a recording wattmeter at a constant specimen temperature of 1770°F.
- e. Figure 3 is a plot of lamp to specimen distance v.s. additional power required (in percent) from power required at lamp to specimen distance of 2 inches. These percentage values were taken from the data presented in Figure 2.
- 2. Figure 4 is a plot of specimen temperature at the control thermocouple locations v.s. temperature lag under the shaded area of the Lux-Therm (LT-1200) double lamp holders for lamp to specimen distances of 2, 3, 4 and 5 inches. The temperature lag under the lamp holders was obtained by taking the difference between thermocouple 19 and the average of thermocouples 12, 17, 33, and 36 (Reference Figure 1). These data were obtained using the heater arrangement, specimen and oven configuration described in Paragraphs 1a, 1b and 1c of Section II. It is noted that two data points are plotted at the 1770°F temperature level. The larger values were recorded 5 seconds after reaching the 1770°F plateau while the lower values were recorded after 10 minutes on the plateau. Specimen temperature was applied by following the programmed time-temperature curve presented in Figure 5. All data of Figure 4 (with the exception of the plateau point at 1770°F) were recorded during transient conditions. If plateaus were established at each temperature level the gradients under the lamp holders would be considerably less. From this data, the optimum lamp to specimen distance was selected at 4 inches. This was the setting used for the X-20 elevon program with good results.
- 3. Figure 6 is a sketch showing temperature gradients along the corrugations of the René panel described in Paragraph 1b, Section II. All data plotted was obtained during the 1770°F temperature plateau of Figure 5 at a lamp to specimen distance of 4 inches.

- 4. Orienting the lamps parallel to the water channels offers two significant advantages (See Figure 7). These are:
- a. Any necessary modifications to the basic reflector "off the shelf" sizes (14-1/2" x 12" or 14-1/2" x 24") can be accomplished with less manhour expenditure.
- b. This arrangement lends itself to reflector slotting (for passage of load straps, deflection devices, etc.) more readily. Test data has shown that under the same set of conditions (that is, same water flow rates, reflector size, power levels, etc.) the two arrangements (lamps perpendicular v.s. lamps parallel to the water channels) will produce the same reflector temperature.
- 5. Because of the load fitting arrangement on the elevon, four 8-inch long slots had to be cut in the reflectors to accommodate the load straps. To accomplish this, four water channels had to be eliminated from the reflectors. Figure 7 and 8 show a typical reflector with slots and the corresponding test temperatures in various locations for both the upper and lower surface reflectors. Since the temperatures are not excessively high in the region of the slots, it appears that sufficient reflector cooling could be accomplished with fewer water channels. This would reduce the reflector cost considerably and also make the reflector more adaptable for slotting, size modification, and so forth. Further test work in this area is being considered. Pertinent notes associated with Figure 7 are as follows:
- a. The heaters shown in Figure 7 were located close to the geometric center of the elevon. Hence, boundary effects are not a consideration.
- b. The reflector temperature data shown were maximum values recorded during the time-temperature excursion of Figure 5.
- c. The maximum upper surface temperature was 1600°F.
- d. The maximum lower surface temperature was 1770°F.
- e. Lamp to specimen distance was 4 inches.

- f. Water flow rates were 4.3 gallons per minute through a reflector area of 4.5 square feet. The water inlet pressure was 80 psig and the outlet pressure was 50 psig.
- g. The change in reflector water temperature (that is, water out water in) was about 20°F.
- 6. Several tests were conducted to determine temperature distributions on load straps and rods that are located in close proximity to the lamps. Figure 9 is a plot of rod temperature distribution as a function of rod length for a given specimen temperature (see Figure 10 for details of test set-up). Figure 11 is a plot of X-20 elevon load strap temperature distribution for both upper and lower surfaces as a function of specimen temperatures. Data for strap temperatures were obtained from thermocouples located just adjacent to the lamps and 18 inches above the specimen surface (See Figure 12). No insulation or forced cooling was used on the load straps.
- 7. Stainless steel lamp holders, without cooling, should not be used to produce sustained specimen temperatures (60 minutes or longer) of 2000°F with power levels around 16 KW per square foot. This is based on test runs conducted with the following parameters:
- a. Specimen Three square feet of builtup panels consisting of .015 inch thick Di-Sil coated molybdenum heat shields (emissivity .80) one inch thick Q-felt insulation blanket backed up by a René 41 corrugated panel. All tests were conducted with the specimen mounted in an insulated oven made from fire brick.
- b. Heater Research, Inc. water cooled reflectors (9 units, each 4 by 12 inches) with a water flow rate of 6 GPM. Each reflector unit contained four 1500 T3/HT General Electric lamps (36 lamps total) mounted in R.I. Model 8352-2 stainless steel double lamp holders. The lamps were oriented parallel to the reflector water channels. No cooling was used for either the lamps or holders. Lamp to specimen distance was 2 inches.

- c. Test Results Seven cycles of temperature application as per the time-temperature curve of Figure 13 were applied to the specimen without any lamp failures. Each cycle had a 2000°F temperature plateau of 17 minutes. During the eighth cycle several lamp holders failed completely due to oxidation of the stainless steel holder. Lamp extension leads were also severely oxidized to the point of failure. The total test time at 2000°F was 130 minutes. Lamp holder oxidation was evident during the third cycle.
- 8. From test data it was determined that lamp (quartz) envelope cooling is a requirement for sustained (90 minutes or longer) specimen temperatures of about 2200°F with power levels around 25 KW per square foot. This is based on a test conducted with the following parameters:
- a. Specimen Typical X-20 wing panel consisting of a Di-Sil coated molybdenum (.015 inches thick) heat shield (emissivity .80), one inch of insulation (Q-felt) backed up by a Rene* 41 corrugated panel. The specimen was 1 square foot in size and was mounted in an insulated oven made from fire brick.
- b. Heater Research, Inc. water cooled reflector (6 GPM water flow rate), Lux-Therm (LT+1200) double lamp holders, 1500 T3/HT General Electric lamps on 1/2 inch centers (24 lamps total) with no cooling air for either the lamps or holders. The lamp to specimen distance was 2 inches.
- c. Test Results Twenty-five kilowatts were applied to the lamps (193 volts and 130 amps) for two hours producing a specimen temperature of 2200°F. There were no distinct lamp failures for this time period, however, after 90 minutes of run time the lamps began to sag in the center. At the conclusion of the test (two hours of run time) this sag was measured at 3/8 inch. Moderate to severe lamp bulging was also evident.
- 9. Evaluation tests were conducted on two Pyrometric Model 602 heaters. These heaters consisted of an all ceramic reflector cast from a refractory oxide with the support fittings made from stainless steel. The lamps are supported by special ceramic holders

- with the lamp end seals and lead wires imbedded in the ceramic holders. This heater is unique in that it requires no cooling whatsoever for specimen temperatures up to 2000°F. All tests were conducted in an insulated oven. The specimen was a typical X-20 wing panel as described in Paragraph II-8a. Each unit measured 6 by 12 inches and contained 6 lamps on 1 inch centers. One unit was tested with six GE 1500 T3/HT lamps while the second unit was tested with six GE 2000 T3/HT lamps. Tests on each unit were conducted separately. No lamp failures or lamp replacements were made for each test sequence. The lamps appeared to be in excellent condition at the termination of the evaluation tests. Test data are tabulated in Tables I and II
- 10. The desired time-temperature profiles for the X-20 Elevon Test Program were generated on two Research, Inc. Model FGE 5110 Data-Trak programmers. These units were modified for controlled cooling (5°F per second) in the event of an emergency abort situation. This modification consisted of installing a clock motor in the unit which drove the program signal down scale at a constant rate when the abort switch was energized. Tests on the modified units produced average decay rates of 4.5°F per second. Requirements for decay rates other than 5°F per second could be satisfied by merely changing the gear ratios in the clock motor assembly.
- 11. The largest control zone size employed for the X-20 Elevon Test Program was one square foot using one thermocouple per zone for control. Control thermocouple reliability was obtained by employing a manually operated switching system that permitted control of one zone with a thermocouple from an adjacent zone in the event of a control thermocouple malfunction. The control zone areas were small enough to permit good control in this manner. Figure 14 illustrates the thermocouple switching system used for the elevon tests. For normal operation with all thermocouples functioning properly the double pole double throw switch is in Position BA. In the event of a thermocouple malfunction, the switch pertaining to the trouble zone is placed in Position BC. Control is then restored by the thermocouple signal

ABLE I

DATA FROM EVALUATION TESTS OF PYRO-METRIC MODEL 602 HEATERS

Remarks	Lamps new at start of test	No lamp or reflector failures	No lamp or reflector failures	No lamp or reflector failures	Lamps in excellent condition. Slight cracks in ceramic reflectors but not serious. Minimum of oxidation on stainless steel support frame. No lamp replacements or failures for tests 1 thru 4. Original lamps and heater used for all tests.
Test Time @2000°F Hours	9.45	4.53	4.50	3.71	22.19
Reflector Temp °F (Max)	942	982	1023	1155	TOTAL
Support Frame Temp °F (Max)	872	986	1050	1103	
Power Level KW/Ft-2	13.94	18.98	21.60	23.82	
Lamp to Specimen Distance	.2"	3,,	3 1/2"	4"	
Specimen Temp (°F)	2000	2000	2000	2000	
Lamp Size (All GE)	1500T3	150013	1500T3	1500T3	
Test No.	т	2	е	4	

TABLE II

DATA FROM EVALUATION TESTS OF PYRO-METRIC MODEL 602 HEATERS

Remarks	Lamps new at start of test	No lamp or reflector failures	No lamp or reflector failures	Lamps in excellent condition at conclusion of tests. Slight cracks in ceramic reflector but not serious. Support frame in good condition. No lamp replacements or failures for tests 1 thru 3. Original lamps and heater used for all tests.
Test Time @2000°F Hours	11.47	4.50	4.58	20.55
Reflector Temp °F (Max)	870	910	915	TOTAL
Support Frame Temp °F (Max)	920	1025	1080	
Power Level KW/Ft-2	13.84	20.88	26.22	
Lamp to Specimen Distance	2"	3"	3 1/2"	
Specimen Temp (°F)	2000	2000	2000	
Lamp Size (All GE)	200013	200013	200013	
Test No.	г	2	e	

from the adjacent zone. This system can only be used if the zone sizes are fairly small and the adjacent zones have the same power requirements.

12. Past test experience has led to an empirical method of establishing Proportional Band settings for the controller units (Research, Inc., General Electric and Westinghouse) to achieve good temperature control. The method discussed below will not always give the best Proportional Band settings for each and every test set-up but in general it provides a good reference starting point. Proportional Band setting K in $^{\circ}F = \frac{(10^{\circ}F) (KW/lamp (max))}{(10^{\circ}F) (MW/lamp (max))}$. The 0.5 KW constants of 10°F and 0.5 KW were established empirically by past test experience. The term KW/lamp (max) defines the maximem KW output for one single lamp based on the maximum power available to the particular temperature zone being considered. For example, determine the approximate Proportional Band setting for a temperature zone consisting of twelve 1500 T3 (GE) lamps wired in series parallel (that is, six sets of two lamps each). A 50 KW Research, Inc. Ignitron unit will be used for power distribution and assume a transmission loss of 10 volts or 590 volts available at the heaters. From the lamp charts it is found that each series parallel lamp set will produce 4.034 KW or 2.017 KW per lamp. Thus, the Proportional Band setting for this will be: $K = \frac{(10^{\circ}F)(2.017 \text{ KW})}{0.5 \text{ KW}} = 40.34^{\circ}F.$ 0.5 KW

The 34-channel load system was originally planned to be used for the X-20 Elevon test program. A dummy jig was erected as a checkout test bed for the system. A load reacting beam was designed to produce equivalent predicted elevon deflections. The maximum expected deflection for the X-20 elevon at the point of load application was only about 1 inch. Many checkout runs were conducted on the dummy test rig and all proved unsatisfactory. Gain settings required to produce correct loading produced severe load cylinder strut oscillations. Based on these results the 34-channel system was dropped in favor of a modified fatigue Edison unit (Model 6SC). The modification consisted of mounting a constant speed motor to a gear box which produced the desired loading rates of two and three minutes (three minutes from zero to maximum load for the up load conditions and two minutes for the down load conditions). The exact hydraulic ram pressure and load rate was determined for each condition in a special jig isolated from the specimen. This system was linear through the entire load spike and proved very satisfactory. See Figure 15 for a plot of actual load v.s. programmed load. The loading rates for this program were quite small, higher rates could produce some nonlinearities.

14. Further checkout work with the 34-channel system led to a stable system by applying pressure to only the tension side of the strut and eliminating the compression side. This is noteworthy and would have application for test programs involving relatively stiff structure.

SECTION III

SUMMARY AND CONCLUSIONS

General conclusions are presented below. These findings are based on the results of tests using the specimen and heater configurations defined in the Discussion Section of this report. Other heaters and specimen combinations will produce somewhat different results but it is felt that this information will be useful for preliminary planning and a guide to establish some general ground rules for elevated temperature testing.

- 1. The power required for specimen equilibrium temperatures in the 1800°F range varies almost linearly with lamp to specimen distance (from 2 inches to 5 inches). The recorded power levels to maintain an equilibrium specimen temperature of 1800°F, for the test set-up discussed in Paragraph II-1, were 8.1, 10.4, 11.9 and 13.2 kilowatts per square foot for lamp to specimen distances of 2, 3, 4 and 5 inches respectively.
- 2. To minimize temperature gradients on the specimen due to lamp holders, gaps between heaters, lamp spacing, and so forth, lamp to specimen distances should never be less than 3 inches. The optimum distance was found to be 4 inches.
- 3. Orienting the lamps parallel rather than perpendicular to the water channels of Research, Inc. Model No. WC-14 water cooled reflectors offers two significant advantages. These are: (1) modifications to the basic "off the shelf" sizes can be accomplished easier and cheaper and (2) the parallel arrangement lends itself to reflector slotting (for passage of load straps, deflection devices, etc.) more readily. Tests have shown that the cooling effectiveness of the reflector is the same for either the parallel or perpendicular arrangement.

- 4. Temperatures on thin (0.022 in.) Rene 41 load straps (not thermally protected) located in close proximity (within 0.125 to 0.25 inches) of the infrared heating lamps will experience temperatures of about 20 to 30 percent higher than the specimen temperature during transient heating rates of 4°F per second. During steady state equilibrium conditions load temperatures just adjacent to the lamps will lead specimen temperatures by about 4 to 5 percent. See Paragraph II-b for details of the load strap and heater configuration (as well as the temperature ranges) used to obtain these data.
- 5. Stainless steel lamp holders, without cooling, should not be used on heater assemblies designed to produce sustained (60 minutes or longer) specimen temperatures of 2000°F with power levels around 16 kilowatts per square foot.
- 6. Infrared lamp (quartz) envelope cooling is a requirement for sustained (90 minutes or longer) specimen temperatures of about 2200°F, or higher, with power levels near or above 25 kilowatts per square foot.
- 7. Pyrometric Model 602 heaters are good for producing specimen temperatures of 2000°F with power levels up to 22 kilowatts per square foot for sustained periods of time (in excess of 20 hours).
- 8. Model FGE 5110 Data-Trak programmers can be easily modified to permit controlled cooling necessitated by an emergency abort situation.
- 9. Model 6SC Fatigue Edison hydraulic load controllers produce a linear load output for loading rates up to 0.8 percent of total load per second.




Figure 1. Specimen and Lamp Arrangement for Power Requirements Tests




Figure 2. Power Required (KW/ft 2) v.s. Distance from Lamps to Specimen




Figure 3. Power Increase (% from 2 inch Reference) v.s. Distance from Lamps to Specimen




Figure 4. Temperature Lag Under LT-1200 Lamp Holders v.s. Temperature Level




Figure 5. X-20 Elevon Time-Temperature Program





Figure 6. Temperature Distributions on Corrugated Rene 41 Panel



Temperature Distributions on Slotted Research, Inc., Water Cooled Reflector Figure 7.




Figure 8. X-20 Elevon Slotted Water Cooled Reflector




Figure 9. Temperature Distribution on Rod in Close Proximity to Heat Lamps





Figure 10. Test Set-Up for Load Rod Temperature Tests



18




Figure 12. Load Strap and Heater Arrangement on X-20 Elevon




Figure 13. Time Temperature Program for Heater Evaluation




Figure 14. Thermocouple Switching System Used for the X-20 Elevon Test Program




Figure 15. Comparison of Actual Load and Programmed Load from Edison Load System

Security Classification

Security Classification		The same of the same of			
(Security classification of title, body of abstract and inde	ONTROL DATA - R&	D			
1. ORIGINATING ACTIVITY (Corporate author)	xing annotation must be e		RT SECURITY C LASSIFICATION		
Structures Test Branch		UNCLASSIFIED			
Structures Division		2 b. GROUP			
Air Force Flight Dynamics Laborate	ory		-000		
3. REPORT TITLE					
DEVELOPMENT TEST SUMMARY IN SUPPOR STRUCTURAL TEST PROGRAM	RT OF X-20 ELEV	ON -			
4. DESCRIPTIVE NOTES (Type of report and inclusive dates) Final					
5. AUTHOR(S) (Last name, first name, initial)					
GROGAN, JOHN C.					
6. REPORT DATE	74. TOTAL NO. OF P	AGES	7b. NO. OF REFS		
January 1966	30		/ NO. OF REFS		
Ba. CONTRACT OR GRANT NO.	94. ORIGINATOR'S R	FPORT NUM	(PED/S)		
	The state of the s	LI DAT HON	DE INCO		
6. PROJECT NO. 1368	AFFDL-TR-65	5-191			
c. Task No. 136804	9b. OTHER REPORT NO(3) (Any other numbers that me this report)				
	thie report)				
d.					
10. AVAILABILITY/LIMITATION NOTICES			-		
The distribution of this document is	unlimited.				
11. SUPPLEMENTARY NOTES	12. SPONSORING MILI	TARY ACT	IVITY		
	Air Force F	light I	ynamics Laboratory		
13. ABSTRACT					
The contents of this report are or test hardware and test techniques contains a general summary of sign development test program conducted Structural Test Program.	involving advan	ced typ	e structures. It		

DD . FORM 1473

UNCLASSIFIED

Security Classification

14.	COLUMN TOTAL	LIN	KA	LINK B		LINKC	
	KEY WORDS	ROLE	WT	ROLE	WT	ROLE	WT
	Test Procedures for Elevated Temperature Structural Testing Test Hardware for Elevated Temperature Structural Testing Testing Hot Structure Infrared Heaters X-20 Elevon Structure						

INSTRUCTIONS

- ORIGINATING ACTIVITY: Enter the name and address of the contractor, subcontractor, grantee, Department of Defense activity or other organization (corporate author) issuing the report.
- 2a. REPORT SECURITY CLASSIFICATION: Enter the overall security classification of the report. Indicate whether "Restricted Data" is included. Marking is to be in accordance with appropriate security regulations.
- 2b. GROUP: Automatic downgrading is specified in DoD Directive 5200.10 and Armed Forces Industrial Manual. Enter the group number. Also, when applicable, show that optional markings have been used for Group 3 and Group 4 as authorized.
- 3. REPORT TITLE: Enter the complete report title in all capital letters. Titles in all cases should be unclassified. If a meaningful title cannot be selected without classification, show title classification in all capitals in parenthesis immediately following the title.
- DESCRIPTIVE NOTES: If appropriate, enter the type of report, e.g., interim, progress, summary, annual, or final. Give the inclusive dates when a specific reporting period is covered.
- 5. AUTHOR(S): Enter the name(s) of author(s) as shown on or in the report. Enter last name, first name, middle initial. If military, show rank and branch of service. The name of the principal author is an absolute minimum requirement.
- 6. REPORT DATE: Enter the date of the report as day, month, year, or month, year. If more than one date appears on the report, use date of publication.
- 7a. TOTAL NUMBER OF PAGES: The total page count should follow normal pagination procedures, i.e., enter the number of pages containing information.
- 7b. NUMBER OF REFERENCES: Enter the total number of references cited in the report.
- 8a. CONTRACT OR GRANT NUMBER: If appropriate, enter the applicable number of the contract or grant under which the report was written.
- 8b, &c, & 8d. PROJECT NUMBER: Enter the appropriate military department identification, such as project number, subproject number, system numbers, task number, etc.
- 9a. ORIGINATOR'S REPORT NUMBER(S): Enter the official report number by which the document will be identified and controlled by the originating activity. This number must be unique to this report.
- 9b. OTHER REPORT NUMBER(S): If the report has been assigned any other report numbers (either by the originator or by the sponsor), also enter this number(s).
- AVAILABILITY/LIMITATION NOTICES: Enter any limitations on further dissemination of the report, other than those

imposed by security classification, using standard statements such as:

- "Qualified requesters may obtain copies of this report from DDC."
- (2) "Foreign announcement and dissemination of this report by DDC is not authorized."
- (3) "U. S. Government agencies may obtain copies of this report directly from DDC. Other qualified DDC users shall request through
- (4) "U. S. military agencies may obtain copies of this report directly from DDC. Other qualified users shall request through
- (5) "All distribution of this report is controlled. Qualified DDC users shall request through

If the report has been furnished to the Office of Technical Services, Department of Commerce, for sale to the public, indicate this fact and enter the price, if known.

- 11. SUPPLEMENTARY NOTES: Use for additional explanatory notes.
- 12. SPONSORING MILITARY ACTIVITY: Enter the name of the departmental project office or laboratory sponsoring (paying for) the research and development. Include address.
- 13. ABSTRACT: Enter an abstract giving a brief and factual summary of the document indicative of the report, even though it may also appear elsewhere in the body of the technical report. If additional space is required, a continuation sheet shall be attached.

It is highly desirable that the abstract of classified reports be unclassified. Each paragraph of the abstract shall end with an indication of the military security classification of the information in the paragraph, represented as (TS). (S). (C), or (U).

There is no limitation on the length of the abstract. However, the suggested length is from 150 to 225 words.

14. KEY WORDS: Key words are technically meaningful terms or short phrases that characterize a report and may be used as index entries for cataloging the report. Key words must be selected so that no security classification is required. Identifiers, such as equipment model designation, trade name, military project code name, geographic location, may be used as key words but will be followed by an indication of technical context. The assignment of links, rules, and weights is optional.